

Your Dawg tags have two Modes "Manual" or "Automatic"

Tags are shipped in Automatic Mode. This is the mode for "Hands Free" operation, your system will arm and disarm automatically. Manual Mode may be useful anytime you are going to be near by your bike but want the system to remain armed, such as at a bike show. When in Manual mode your system will arm 30 seconds after your ignition is turned off and will require that you to push the black button on the Dawg Tag before starting your bike.

Dawg Tag



Switching from "Manual" mode to "Automatic" mode.

Automatic Mode (Passive)

Press and hold down both buttons on the Dawg Tag until the LED goes out. (approximately 5 seconds) After the LED light goes out, the Dawg Tag will flash 5 times to acknowledge the system is in AUTOMATIC mode.

Manual Mode - Press and hold down both buttons on the Dawg Tag until the LED goes out. (approximately 5 seconds) After the LED light goes out, press the large BLACK button 2 times consecutively, after pressing the BLACK button two times. The Dawg Tag will flash 3 times to indicate you are in MANUAL mode

The Dawg tag can be toggled from manual to Automatic Mode and back again by simply repeating this procedure. *** if you purchased multiple Dawg Tags you may want to only put one of them into Automatic mode and store your spare Dawg Tag in Manual mode, This will extend battery life.